



PC CONTROL & FUNCTION

Control the camera from your PC



QUICK MARK-UP, ANNOTATION AND ARCHIVE IMAGE/DATA

Record notes, faults and dimensions effortlessly



AUTOMATIC CALIBRATION LOADING

Select magnification and measure



FIELD OF VIEW CORRECTION

Additional calibration to reduce lens distortion and increase accuracy



PARCENTRICITY CORRECTION

Linking of different zoom positions




PRE-SET MAGNIFICATION SETTINGS

With factory set pixel and FOV calibration




ENHANCED MEASUREMENT FEATURES

Point, line, circle, arc, distance and angle



QUICK PART ALIGNMENT AND DATUM

For feature positions and aligned dimensions



AUTOMATIC EDGE DETECTION

Measure features quickly and accurately